





Parts Breakdown

HR5000

Products with multiple versions are listed in subsiding order with the newest version on top not indented

<u>Fig #</u>	<u>Part ID</u>	<u>Part Name</u>	<u>Quantity</u>
1	254231-5	KEY 4, HR3851	3
2	316068-9	BARREL, HR5000	1
3	213707-1	O RING 65, HM1100C	1
4	214653-1	P. BEARING 52, HR5000	1
5	267044-5	F. WASHER 52, HR5000	1
6	221380-3	SPIRAL B. GEAR 41, HR5000	1
7	322155-4	STRIKER, HR5000,T1	1
7	323751-1	STRIKER, HR5000, T2	1
8	213481-1	O-RING 32, HR5000, T2	1
8	412049-2	PISTON RING 40, HM1211	1
10	213481-1	O-RING 32, HR5000, T2	1
10	412049-2	PISTON RING 40, HM1211	1
12	256120-0	PIN 10, HM1211	1
13	321441-0	PISTON, HM1211	1
13	323750-3	PISTON, HR5000, T2	1
14	150046-7	CRANK CAP, HR5000	1
15	213754-2	O RING 71, HR5000	1
16	315419-3	CONNECTING ROD, HR5000	1
17	212208-6	N. BEARING 1516, HR5000	1
18	153176-3	CRANKSHAFT, HR5000	1
19	254001-2	WOODRUFF KEY 4, HM1810	2
20	254001-2	WOODRUFF KEY 4, HM1810	1
21	962251-2	RETAINING RING R-52, HR5000	1
22	211314-4	BALL BEARING 6304, HM1211,T1	1
22	211327-5	BALL BEARING 63604LLU, HR5000	1
23	213656-2	O RING 53, AN451	1
24	157868-6	CRANK HOUSING, HR5000	1
24	158573-8	CRANK HOUSING, HR5000	1
25	221761-1	H. GEAR 41, HR5000	1
26	221957-4	S. GEAR 24, HR5000	1
27	212113-7	N. BEARING 1212, LS1440	1
28	263005-3	RUBBER PIN 6,LS1013	1
29	213906-5	O RING 113, HR5000-T1	1
29	421690-0	SEAL RING, HR5000	1
30	157867-8	GEAR HOUSING, HR5000	1
30	157867-8	GEAR HOUSING, HR5000	1
31	253787-5	F. WASHER 16, 2030N	1
32	210004-6	BALL BEARING 638, HR5000	1
33	253865-1	F. WASHER 8, HR5000	1
34	231446-1	COMP. SPRING 12, HR5000	1
35	134499-8	TORQUE LIMITER ASS'Y	1
36	253310-6	T. WASHER 10, HR5000	1
37	153174-7	GEAR COMPLETE, HR5000	1
38	212359-5	N. BEARING 2216, HR3851	1
39	212011-5	N.BEARING 609,JS1600	1
40	961011-9	STOP RING E-4, 4301BV	1
41	213055-8	O RING 10, HR3851	1
42	322187-1	CHANGE SHAFT, HR5000	1
43	342786-3	PLATE, HR3851	1
44	216002-8	STEEL BALL 4.8, NHP1310	1
45	231317-2	COMP. SPRING 3, HR3851	1
46	410331-3	CHANGE LEVER, HR3851	1
47	941052-1	F. WASHER 4, 9218SB	1
48	922126-7	H.S.H. BOLT M4X16, 4330DWA	1
49	942101-7	SPRING WASHER 5, 9005B	2
50	922212-4	H.S.H. BOLT M5X12, AF502	2
51	322156-2	IMPACT BOLT, HR5000	1
52	267043-7	F. WASHER 43, HR5000	1
53	211469-5	BALL BEARING 6907, HR5000	1
54	252119-3	NUT M34. 8-41,HR5000	1
55	213420-1	X RING 28, HR5000-T1	1
55	213428-5	X-RING 28, HR5000	1
56	213411-2	O RING 27, HR3851	1
57	213663-5	O RING 55, HR5000	1



Parts Breakdown

HR5000

58	331132-5	TOOL RETAINER, HR5000	1
59	322203-9	TOOL HOLDER, HR5000	1
60	231281-7	COMP. SPRING 15, HM1500	1
62	252046-4	HEX NUT M8-13, HR5000	1
63	922451-6	H.S.H. BOLT M8X30, LS1013FL	4
64	152396-6	CYLINDER LINER, HR5000	1
65	213459-4	O RING 32, HK1810	1
66	211129-9	BALL BEARING 6201DDW, N9501B	1
67	213160-1	OIL SEAL 14, HR3851	1
68	241634-2	FAN 94, HR3851	1
69	514886-1	ARMATURE ASSY 115V, HR5000	1
70	681624-7	INS. WASHER, HM1800,T1	1
70	681635-2	INSULATION WASHER, HM1211B	1
71	211066-7	B. BEARING 6200LLB, BO4552	1
71	211087-9	B. BEARING 6200DDW, JR3000V	1
72	213406-5	O RING 30, HR5000	1
73	265346-3	HEX BOLT M5X55, HR5000	2
75	524831-8	FIELD ,HR5000	1
76	953106-2	RIVET 0-5, HM1500	4
77	855983-7	NAME PLATE, HR5000	1
78	159054-5	MOTOR HOUSING, HR5000	1
79	643650-4	BRUSH HOLDER CAP, 5007MG	2
80	181048-2	CARBON BRUSH 155, HR5000	1
80	194987-7	CARBON BRUSH SET CB-155, HR5000	1
81	284055-5	REAR COVER, HR3851	1
82	942101-7	SPRING WASHER 5, 9005B	2
83	922221-3	HEX BOLT M5X16, 6906	2
83	922222-1	H.S.H. BOLT M5X16, HM1211B	2
84	922376-4	H.S.H. BOLT M6X55, HR5000	4
85	941151-9	F. WASHER 6, 5007NB	4
88	152343-7	SIDE HANDLE CPL.,HR5000	1
88	416061-4	SIDE HANDLE, HR5000	1
89	252640-2	WING NUT M8, HM1100C	1
89	259020-3	WING NUT M10, HR5000,T1	1
91	265439-6	HEX BOLT M8X150, HM1100C	1
91	265902-9	SET BOLT M10X20, HR5000,T1	1
94	922316-2	HEX BOLT M6X14, HR3851	2
96	343754-9	CUSHION PLATE, HR3851 (T2)	2
97	265914-2	H.S.H.BOLT M6X25, HM1211B	2
99	421265-5	DUST COVER, HR3851	1
100	911129-6	P.H. SCREW M4X16, HR5000	1
101	651145-3	SWITCH, HM1211B	1
102	931302-2	HEX NUT M6, HR2400	1
103	942151-2	SPRING WASHER 6, 5007NB	1
104	941151-9	F. WASHER 6, 5007NB	1
105	263002-9	RUBBER PIN 4, HR2400	1
108	263002-9	RUBBER PIN 4, HR2400	1
109	321210-9	HANDLE SHAFT, HR3851	1
110	182077-8	HANDLE SET, HR5000	1
111	682505-8	CORD GUARD, 2711	1
111	682568-4	CORD GUARD, HR5000	1
112	664276-9	CORD (2X16X16 SJ), HR5000	1
113	687001-1	STRAIN RELIEF, 6013BR	1
114	911133-5	P.H. SCREW M4X18, N9501B	2
115	182077-8	HANDLE SET, HR5000	1
116	911243-8	P.H. SCREW M5X25, GA7911	2
117	262051-3	RUBBER RING, HR3851	2
118	262052-1	RUBBER RING 9, HR3851	2
119	257636-8	SLEEVE 6, HR3851	2
120	414774-1	HANDLE BASE, HR5000,T1	1
120	416060-6	UPPER HANDLE BASE, HR5000,T2	1
120	416480-4	UPPER HANDLE BASE,HR5000,T3	1
121	416089-2	LOWER HANDLE BASE, HR5000,T2	1
121	416481-2	LOWER HANDLE BASE,HR5000,T3	1
122	151768-2	SIDE HANDLE 62 CPL.,HR5000	1
122	344387-3	HANDLE SPRING 62, HR5000,T1	1
122	344617-2	HANDLE SPRING 62,HR5000,T2	1



Parts Breakdown

HR5000

123	211469-5	BALL BEARING 6907, HR5000	1
400	150589-9	PLASTIC TOOL CASE,HR3851,HR5000	1
401	783202-0	HEX WRENCH 4, JR3000V	1
404	273472-4	GRIP 32, HR3851	1
500	134797-0	SIDE HANDLE ASSEMBLY, HR5000,T2	1
500	134887-9	SIDE HANDLE ASS'Y, HR5000	1
900	810246-8	N/A	1