



Model BJV180 Parts List

A = Standard Equipment

○ = Circuit Diagram

Fig.	Part No.	Description	Q'ty	Unit
1	188207-9	HANDLE SET	1	
	D10	INC. 25		
2	266048-4	TAPPING SCREW 4X40	1	PC.
3	266091-3	TAPPING SCREW 4X50	1	PC.
4	265995-6	TAPPING SCREW 4X18	5	PC.
5	442138-9	PACKING	1	PC.
6	214031-5	PLANE BEARING 4	1	PC.
7	232207-2	LEAF SPRING	1	PC.
8	256117-9	PIN 4	1	PC.
9	911111-5	PAN HEAD SCREW M4X10	2	PC.
10	911111-5	PAN HEAD SCREW M4X10	2	PC.
11	345240-6	LINEAR GUIDE	1	PC.
12	345240-6	LINEAR GUIDE	1	PC.
13	153338-3	GEAR HOUSING COVER COMPLETE	1	PC.
	C10 253313-0	THIN WASHER 14	1	PC.
	C20 257250-0	RING 20	1	PC.
	C30 421815-6	DUST SEAL 8	1	PC.
14	631744-7	LIGHT CIRCUIT	1	
15	689070-8	HEAT SINK	1	PC.
16	911006-2	PAN HEAD SCREW M3X8	1	PC.
17	232152-1	LEAF SPRING	1	PC.
18	419613-0	LOCK OFF BUTTON	1	PC.
19	650584-4	SWITCH C3LA-2A-PLSR	1	
20	233118-4	COMPRESSION SPRING 4	1	PC.
21	419754-2	SWITCH LEVER	1	
22	324233-6	SAFETY WIRE	1	PC.
23	266034-5	TAPPING SCREW CT 4X16	4	PC.
24	643812-4	TERMINAL	1	PC.
25	188207-9	HANDLE SET	1	
	D10	INC. 1		
26	268090-1	PIN 4	1	PC.
27	961017-7	STOP RING E-3	1	PC.
28	310134-4	SLIDER	1	PC.
29	231659-4	TORSION SPRING 6	1	PC.
30	419820-5	TOOL OPENER	1	
31	265026-1	+ PAN HEAD SCREW	1	PC.
32	310135-2	PUSH PIN	1	PC.
33	421817-2	DUST COVER	1	PC.
34	962068-3	RETAINING RING R-18	1	PC.
35	165326-8	ROD	1	PC.
36	231660-9	TORSION SPRING 15	1	PC.
37	310136-0	BLADE HOLDER	1	PC.
38	188208-7	MOTOR HOUSING SET	1	
	D10	INC. 63		
39	265995-6	TAPPING SCREW 4X18	4	PC.
40	862966-0	BJV180 NAME PLATE	1	
41	638504-8	ENDBELL COMPLETE	1	
42	638373-7	YOKE UNIT	1	
43	619206-5	ARMATURE	1	
44	961004-6	RETAINING RING S-8	1	PC.
45	212014-9	NEEDLE BEARING 407	1	PC.
46	265353-6	HEX. SOCKET HEAD BOLT M4X12	2	PC.
47	153336-7	CRANK COMPLETE	1	PC.
48	313108-4	BALANCE PLATE	1	PC.

	49	158168-7	GEAR COMPLETE	1	
	50	345235-9	PUSH PLATE	1	PC.
	51	253877-4	FLAT WASHER 8	1	PC.
	52	266050-7	TAPPING SCREW 4X30	4	PC.
	53	961018-5	STOP RING E-5	1	PC.
	54	417839-8	SEAL PLATE	1	PC.
	55	286032-3	CAP 5	1	PC.
	56	233139-6	COMPRESSION SPRING 3	1	PC.
	57	272244-4	LEVER 17	1	PC.
	58	268063-4	PIN 4	1	PC.
	59	158169-5	GEAR HOUSING COMPLETE	1	
	60	252171-1	SQUARE NUT M5-8	1	PC.
	61	421816-4	DUST SEAL	1	PC.
	62	153334-1	RETAINER COMPLETE	1	PC.
	63	188208-7	MOTOR HOUSING SET	1	
		D10	INC. 38		
	64	191971-3	CARBON BRUSH CB-430	1	SET
	65	643807-7	BRUSH HOLDER CAP	2	PC.
	66	232208-0	LEAF SPRING	1	PC.
	67	922226-3	HEX. SOCKET HEAD BOLT M5X18	1	PC.
	68	345237-5	CRANK PLATE	1	PC.
	69	317565-8	BASE	1	PC.
	70	912107-9	COUNTERSUNK HEAD SCREW M4X8	4	PC.
	71	345238-3	BASE PLATE	1	PC.
A	A01	415524-7	ANTI-SPLINTERING DEVICE	1	PC.
A	A02	417852-6	COVER PLATE	1	PC.
A	A03	792473-8	JIG SAW BLADE B-22	1	SET
A	A04	792529-7	JIG SAW BLADE B-10	1	SET
A	A05	792729-9	JIG SAW BLADE BR-13	1	SET
A	A06	783202-0	HEX. WRENCH 4	1	PC.
A	A07	DC18RA	DC18RA FAST CHARGER	1	
A	A08	194205-3	BATTERY BL1830 SET	2	PC.
A	A09	824775-5	PLASTIC CARRYING CASE	1	
	A10	862981-4	BJV180 MODEL NO. LABEL	1	
○	D01	652038-7	PAN HEAD SCREW M3X8	2	PC.
○	D02	654037-5	INSULATED TERM. RBV1.25-3.5T	2	PC.
○	D03	654208-4	RECEPTACLE	2	PC.